

QuickSetUp Guide for all OKI CMY+W Printers and SpaceControl4

**Note: Only Windows/PC compatible via USB!
Not compatible with Mac and Network.**

1. Install Driver and Printer according OKI's original SetUp instruction.

Note: Before installing SpaceControl4 make sure the Printer is connected via a USB cable, Driver installed and powered on!

2. Install SpaceControl4 via the Setup.exe and follow the dialog.

3. Launch SpaceControl4.

4. Select the 'Utility' tab and select 'License Install'. Find the License File you received from us and select 'Open'. Your License will install and window will close.

5. Select the 'Utility' tab and select 'Printer Mode'. If you wish to use the SpaceControl4 Print Utility press the 'Driver Off' button.

Congratulation! Your Printer is now ready to work with SpaceControl4 by TheMagicTouch. If you encounter any trouble please contact us via:
<http://www.themagictouch.com/copyprob.html>